

Sony Ericsson T610 to Epson PictureMate via Bluetooth **Sony Ericsson Z600 to Epson PictureMate via Bluetooth**

Notes:

Camera phone resolution can be set in Menu - Camera – Select – More – Size – Select. Settings are **Large (288x352)** or **Small (120x160)**.

Camera phone Bluetooth can be set via Menu – Connectivity – Select – Bluetooth – Select – Turn On.

PictureMate Configuration of the Bluetooth option is from the front panel (refer OnLine Reference Guide – Using the Bluetooth Photo Print Adapter).


1. At the Sony Ericsson **Menu** – choose **Camera**. Then **Select**.



2. Choose **More**





My pictures - Select



Choose a picture – then **More**



3. Choose **Send** – **Select** **Via Bluetooth** - **Select**



4. Choose **PictureMate** – **Select**

